

IMPORTANT INFORMATION

Read this information before proceeding. It is the user's responsibility to take the following precautions at all times.

CAUTION:

- Always stake or weight down your E-Z UP®. Do not use in any potentially windy or rainy weather. Wind and rain can damage the E-Z UP® Brand Shelter and may also result in injury to you or others. Therefore, do not rely on shelter for protection in heavy or prolonged rain storms.
- The E-Z UP® Brand Shelter is designed as a temporary shelter. Do not leave up for extended periods.
- Use caution when handling the E-Z UP® folding frame. Avoid pinching hands or fingers as frame opens or closes.
- Do not use shelter in a lightning storm.
- Do not leave your E-Z UP® Brand Shelter unattended.
- Do not build fires within shelter enclosure.

WARNING: Keep all flame and heat sources away from fabric. This fabric meets the flammability requirements of CPAI-84. The fabric may burn if left in continuous contact with any flame source. The application of any foreign substance to the tent may render the flame-resistant properties ineffective.

CARE AND MAINTENANCE

For long lasting durability and the best possible protection for your E-Z UP® Brand Shelter, follow these E-Z care and maintenance instructions:

- Use a mild soap (not detergent) and plenty of water for top cleaning.
- Let the E-Z UP® top and frame dry completely before closing or storing to avoid mildew.
- Frame will operate and look better if occasionally wiped with silicone spray, especially before and after use in damp conditions. Remove excess silicone residue before applying top.
- Slightly tighten bolts if frame becomes loose.

For online warranty, service, parts and accessories as E-Z as 1-2-click, contact us at

www.ezup.com

Ask about our other E-Z UP® Brand Products



2 YEAR WARRANTY

INTERNATIONAL E-Z UP, INC., manufacturer of the E-Z UP® Brand Product, warrants to the original purchaser who provides a dated sales receipt, each part of the E-Z UP® Product to be free from defects in material or workmanship for a period of two years after the date of original purchase. The E-Z UP® frame is covered under a limited two year warranty and guarantees the frame to be free from defects in material or workmanship. This warranty applies only for normal and expected uses, as determined by the manufacturer.

INTERNATIONAL E-Z UP, INC.'s obligation and liability under this warranty is limited to the repair or replacement (at its option) of the product or its parts, after its own review and examination.

RETURN ADVISORY - Before returning any part or complete product to INTERNATIONAL E-Z UP, INC. Please phone or write to obtain specific return shipping instructions. All shipping costs must be prepaid, and INTERNATIONAL E-Z UP, INC. is not responsible for products damaged in transit.

CONDITIONS - This limited warranty shall be void as to any product which has been altered or modified in any manner. This warranty does not apply to damages caused by wind, rain, or other forces of nature, not to accidental or deliberated damage of the product, nor to use of the product that does not conform with the product instructions.

This warranty is provided in lieu of all other warranties, expressed or implied.

We Make Life E-Z!™

INTERNATIONAL E-Z UP, INC.

1601 Iowa Avenue, Riverside, California 92507

(909) 426-0060 • Fax (909) 426-0063

www.ezup.com

Customer Service Hot Line

800-SHADE ME

7 4 2 3 3 6 3

E-Z UP® INSTANT SHELTER®



"Sets Up in Seconds!"™



10' x 10'

Take time to learn how to provide years of durable and safe use from your E-Z UP® Brand Shelter. After reading these instructions carefully, if you have any need of assistance, call our Customer Service Department.



Customer Service Hot Line

(800) SHADE ME

7 4 2 3 3 6 3

www.ezup.com

OWNER'S MANUAL


INSTRUCTIONS

Please read each step before you attempt to set up.
Save these instructions for future reference.


- Craft Dome™ Steel Frame
- Dura-Last® Commercial Top
- Awning Fabric
- 2 Awning Poles
- 4 Piece Stake Kit
- 4 Zippered Dura-Lon™ Sidewalls
- Roller Bag
- Name Banner Fabric

*Note: First Time Attachment Is Required.


Top and frame are packed separately. A first time set up requires that top be bolted on to the frame. This first time set up takes longer than future set ups. Once top is permanently attached to frame, it does not need to be removed and set up and take down are easily accomplished within seconds.



1. Place your E-Z UP® frame in the center of area to be sheltered. With partner on opposite side, grasp two outer legs, slightly lift off ground and step backwards, stopping at full arms' length - approximately 3/4 its total size.






2. Unfold the fabric top ensuring the roof vents in the top are located on the adjacent side to the Open/Close truss labels.



3. To secure the top to frame, locate the two 'Top Attachment Nuts' on the Frame.

Unscrewing the hex nuts on the vented ends is not necessary.



***Note:** Once top is permanently attached, only perform steps 1 and 5 - 8 to set up.

4. Unscrew top attachment nut from bolt. Place top fabric with grommet over each bolt, screw on top attachment nut and tighten until snug. Top should rotate easily - do not over-tighten. Repeat this procedure on the remaining grommet.

5. Grasp the bottom of the diamond shaped area of trusses on opposite sides by the "open" sticker. Lift up and step backwards shaking the shelter until fully opened, being careful not to pinch fingers.

6. In order to engage pull pin, pull the top's hook & loop corners away from the frame. Engage pull pin at each corner by pushing up on trusses while holding down on top of leg with other hand until pin engages.

7. Finally attach the top to the E-Z UP® frame by matching hook & loop strips on the top with the hook & loop strips on the frame. Pull the corners down fully. Push the hook & loop firmly together at each corner.

8. Lift two adjacent outer legs up and slide out the inner legs until the snap button locks. Repeat on the opposite legs - make sure to do two legs at a time.

Roof VENTS

Note: Roof vents should be opened in windy conditions or for ventilation. Both vents should be opened for full effect.




1. Locate Zippers and un-zip roof vent.



2. Roll the flap downward and finally attach the toggle & loop straps together to secure.


How To TAKE DOWN



1. With partner, slightly lift up two adjacent outer legs 1", depress snap button and telescope inner legs into outer legs lowering the unit. Repeat on the opposite legs - making sure to do two legs at a time.




2. Release the pull pin at each corner. With one hand, push up on the truss near the pull pin and pull the ring out to release.



NOTE: Pay special attention to this step!

3. Grasp each of the four legs one at a time, shake the trusses up and down vigorously to overcome the heavy duty top resistance to close the frame.



4. Grasp the top diamond on opposite sides by "close" sticker. Lift the shelter up slightly and shake it while stepping towards your partner until the unit is 3/4 closed. With each partner grasping two outer legs, pull frame together to fully close it - **Be careful not to pinch fingers.**