

## IMPORTANT INFORMATION

**IMPORTANT!** Read this information before proceeding. It is the user's responsibility to take the following precautions at all times.

- Always stake or weight down your E-Z UP® shelter. Do not use in any potentially windy or rainy weather. Wind and rain can damage your E-Z UP® shelter and may also result in injury to you or others. Therefore, do not rely on shelter for protection in heavy or prolonged rain storms.
- The E-Z UP® shelter is designed as a temporary sun shelter. Do not leave up for extended periods.
- Use caution when handling the E-Z UP® frame. Avoid pinching hands or fingers as frame opens or closes.
- Do not use shelter in a lightning storm.
- Do not leave your E-Z UP® Instant Shelter® product unattended.
- Do not build fires within shelter enclosure.

**WARNING:** Keep all flame and heat sources away from the top, awning and sidewall fabrics. These fabrics meet the flammability requirements of CPAI-84. The fabric may burn if left in continuous contact with any flame source. The application of any foreign substance to the fabric may render the flame-resistant properties ineffective.

## CARE AND MAINTENANCE

For long lasting durability and the best possible protection for your E-Z UP® Instant Shelter® product, follow these E-Z care and maintenance instructions:

- Use a mild soap (not detergent) and plenty of water for top cleaning.
- Let the E-Z UP® top and frame dry completely before closing or storing to avoid mildew.
- Frame will operate and look better if occasionally wiped with silicone spray, especially before and after use in damp conditions. Remove excess silicone residue before attaching top.
- Use a seam sealer if top leaks or drips water. Available at most sporting goods and hardware stores.
- Slightly tighten bolts if frame becomes loose.

For online warranty, service, parts and accessories as E-Z as 1-2-click, contact us at

[www.ezupdirect.com](http://www.ezupdirect.com)

Ask about our other E-Z UP® Instant Products™

EZS101QWHP R01 OVO28



**3 YEAR**

**WARRANTY**

INTERNATIONAL E-Z UP, INC., manufacturer of the E-Z UP® Instant Shelter® product, warrants to the original purchaser who provides a dated sales receipt, each part of the E-Z UP® shelter to be free from defects in material or workmanship for a period of three years after the date of original purchase. The E-Z UP® Instant Shelter® frame is covered under a limited three year warranty and guarantees the frame to be free from defects in material or workmanship. This warranty applies only for normal and expected uses, as determined by the manufacturer.

INTERNATIONAL E-Z UP, INC.'s obligation and liability under this warranty is limited to the repair or replacement (at its option) of the product or its parts, after its own review and examination.

RETURN ADVISORY - Before returning any part or product to INTERNATIONAL E-Z UP, INC. or its designated representative, please phone or write to obtain specific return shipping instructions. All shipping costs must be prepaid, and INTERNATIONAL E-Z UP, INC. is not responsible for products damaged in transit.

CONDITIONS - This warranty shall be void as to any product which has been altered or modified in any manner. This warranty does not apply to damages caused by wind, rain, or other forces of nature, not to accidental or deliberated damage of the product, nor to use of the product that does not conform with the product instructions.

This warranty is provided in lieu of all other warranties, expressed or implied.

**We Make Life E-Z!™**

**INTERNATIONAL E-Z UP, INC.**

1601 Iowa Avenue, Riverside, California 92507

(909) 426-0060 • Fax (909) 426-0063

[www.ezup.com](http://www.ezup.com)

Customer Service Hot Line

**1 (800) SHADE ME**

7 4 2 3 3 6 3

OWNER'S MANUAL

## E-Z UP® INSTANT SHELTER® PRODUCT



**"Sets Up in Seconds!"™**

**10ft x 10ft  
(3.05m x 3.05m)**

Take time to learn how to provide years of durable and safe use from your E-Z UP® Instant Shelter® product. After reading these instructions carefully, if you have any need of assistance, call our Customer Service Department.



**Customer Service Hot Line**

**1 (800) SHADE ME**

7 4 2 3 3 6 3

[www.ezupdirect.com](http://www.ezupdirect.com)

# INSTRUCTIONS

Please read each step before you attempt to set up.  
Save these instructions for future reference.

- E-Z UP® Instant Shelter® frame
- Dura-Last® Commercial Top
- 4 Piece Stake Kit

- See other instructions in Warranty Kit
- 4 Zippered Dura-Lon™ Sidewalls
  - Awning Fabric
  - 2 Awning Poles
  - Roller Bag
  - Name Banner Fabric

## FIRST TIME TOP ATTACHMENT




**1.** Place your E-Z UP® frame in the center of area to be sheltered. With partner on opposite side, grasp two outer legs, slightly lift off ground and step backwards, stopping at full arms' length - approximately 3/4 its total size.




**2.** Gently unfold the fabric top and place it over the open frame.



**3.** Attach the fabric top to the E-Z UP® frame by matching hook & loop strips on the top with the hook & loop strips on the frame. Pull the corners down fully.




**4.** To secure the top to frame, line up grommet holes on fabric top with the bolts on frame.



**5.** Unscrew top attachment nut from bolt on frame. Place top fabric with grommets over each bolt, screw on top attachment nut and tighten until snug. Fabric top should rotate easily - do not over-tighten. Repeat this procedure on the remaining grommets.

## How To SET UP

First: Repeat Step 1, in 'First Time Top Attachment'



**1.** Grasp the bottom of the diamond shaped area of trusses on opposite sides by the "open" sticker. Lift up and step backwards until shelter is fully opened, being careful not to pinch fingers.



**2.** Pull the fabric top corners away from the frame as shown. Engage pull-pin slider at each corner by pushing up on trusses with one hand while holding down on top of leg with other hand until pull pin slider engages. Pull down fabric top corner and repeat on other legs.




**3.** Lift two adjacent outer legs up 1" and slide out the inner legs until the snap button locks. Repeat on the opposite legs - make sure to do two legs at a time on same side.

## How To TAKE DOWN




**1.** With partner, slightly lift up two adjacent outer legs 1", depress snap button and slide inner legs into outer legs. Repeat on the opposite legs - making sure to do two legs at a time on same side.



Pull Pin

**2.** Release the pull pin slider at each corner by first lifting fabric top corner and pull the pin out to release.



**3.** Grasp the top diamond on opposite sides by "close" sticker. Lift the shelter up slightly and shake it while stepping towards your partner until the unit is 3/4 closed. With partner grasp two outer legs and push frame together to fully close it.

**Be careful not to pinch fingers.** Store shelter in roller bag. (See Roller Bag Instruction Enclosed within your Warranty Kit).