

## IMPORTANT INFORMATION

**IMPORTANT!** Read this information before proceeding. It is the user's responsibility to take the following precautions at all times.

- Use caution when handling the E-Z UP® Instant Shelter® folding frame. Avoid pinching hands or fingers as frame opens or closes.
- Always stake or weight down your E-Z UP® Instant Shelter®. Do not use in any potentially windy situations. Immediately take down in any windy conditions.
- Do not leave unattended in windy or rainy weather. Wind and rain can damage the E-Z UP® Instant Shelter® and may also result in injury to you or others. Therefore, do not rely on canopy for protection in heavy or prolonged rain storms.
- Do not use your E-Z UP® Instant Shelter® in a lightning storm.
- The E-Z UP® Instant Shelter® is designed as a temporary shelter. Do not leave up for extended periods.
- Do not leave your E-Z UP® Instant Shelter® unattended.
- Keep all flame and heat sources away from top fabric. Do not build fires within shelter enclosure.

Fire retardant - meets CPAI-84 requirements.

## CARE AND MAINTENANCE

**For longer lasting durability and the best possible protection for your E-Z UP® Instant Shelter®, follow these E-Z care and maintenance instructions.**

- Use a mild soap (not detergent) and plenty of water for top cleaning.
- Let the E-Z UP® Instant Shelter® top and frame dry completely before closing or storing to avoid mildew.
- Frame will operate and look better if wiped with silicone spray occasionally, especially before and after use in damp conditions. Remove excess silicone residue before applying top.
- Use a seam sealer if top leaks or drips water. Seam sealers are available at most hardware stores.
- Slightly tighten bolts if frame becomes loose.

**For online warranty, service, parts and accessories as E-Z as 1-2-click, contact us at**

**[www.ezup.com](http://www.ezup.com)**

**Ask about our other E-Z UP® Instant Products™**



## PRODUCT WARRANTY

INTERNATIONAL E-Z UP, INC., manufacturer of the E-Z UP® Instant Shelter®, warrants to the original purchaser who provides a dated sales receipt, each part of the E-Z UP® Instant Shelter® to be free from defects in material or workmanship for a period of one year after the date of original purchase. This warranty applies only for normal and expected uses, as determined by the manufacturer. INTERNATIONAL E-Z UP, INC.'s obligation and liability under this warranty is limited to the repair or replacement (at its option) of the product or its parts, after its own review and examination.

**RETURN ADVISORY** - Before returning any part or product to INTERNATIONAL E-Z UP, INC. or its designated representative, please phone or write to obtain specific return shipping instructions. All shipping costs must be prepaid, and INTERNATIONAL E-Z UP, INC. is not responsible for products damaged in transit.

**CONDITIONS** - This warranty shall be void as to any product which has been altered or modified in any manner. This warranty does not apply to damages caused by wind, rain, or other forces of nature, not to accidental or deliberated damage of the product, nor to use of the product that does not conform with the product instructions.

This express warranty is provided in lieu of all other warranties, expressed or implied.

## We Make Life E-Z!™ INTERNATIONAL E-Z UP, INC.

Corporate and Manufacturing Headquarters  
1601 Iowa Avenue, Riverside, California 92507  
(909) 426-0060 • Fax (909) 426-0063  
[www.ezup.com](http://www.ezup.com)

Customer Service Hot Line  
**800-SHADE ME**

7 4 2 3 3 6 3

OWNER'S MANUAL

## E-Z UP® INSTANT SHELTER®



**"Sets Up in Seconds!"™**

**Cabana™**  
**10' x 10'**

Take time to learn how to provide years of durable and safe use from your E-Z UP® Instant Shelter®. After reading these instructions carefully, if you have any need of assistance, call our Customer Service Department.



**Customer Service Hot Line**  
**(800) SHADE ME**  
7 4 2 3 3 6 3  
[www.ezup.com](http://www.ezup.com)

# WHAT'S IN THE BOX

Please read each step before you attempt to set up. Save these instructions for future reference.

- 1- 10' x 10' Cabana™ Frame Fully Assembled
- 1- Cabana™ Top
- 1 - Carry Bag
- 4- Piece Stake Set

## How To SET UP

### Note: First Time Attachment Is Required

Top and frame are shipped unattached to avoid damage. A first time set up requires that top be bolted on to the frame. This first-time set up will take longer than future set ups. Once top is permanently attached to frame, set up and take down are easily accomplished within seconds.

**1.** Place your E-Z UP® frame in the center of area to be shaded. With partner on opposite side, grasp outer legs, lift off the ground, and step backwards - stopping at full arm's length - approximately 3/4 it's total size.



**\*2.** Gently unfold the fabric top and place it over the open frame.



**\*3.** Attach the Cabana™ top to the E-Z UP® frame by placing the four corner pockets over the end of all four top extensions.



**\*4.** With screwdriver, put screw through grommet hole into the pre-drilled hole and secure on all four top frame extensions.



**5.** Grasp the top and bottom of the diamond shaped area of trusses, on opposite sides. Lift up and step backwards until shelter is fully opened. **Be careful not to pinch fingers.**



**6.** Engage the auto slider at each corner by pushing up with one hand while holding down the top of the leg with the other hand. The snap button will engage the hole. Repeat at all four corners.




**7.** Stand under shelter and locate center hub. Place hand beneath center hub and push up, extending top frame inner peak beams. Keep hand in place and push up until at least two inner peak beams lock.



**Warning: Do not let go of center hub until at least two peak beam assemblies lock. Extend remaining top frame inner peak beam by pulling apart so that all four tubes are snapped into place.**

**8.** Pull out top extension rods until the snap button engages the hole.



**9.** Lift two adjacent outer legs up 1" and slide out the inner legs until the snap button locks. Repeat on the opposite legs - make sure to do two legs at a time.



**\*Note:** Once top is permanently attached only perform steps 1 and 5-9 to set up.

# How To TAKE DOWN

**1.** With partner, slightly lift two adjacent outer legs up 1", depress the snap button, and telescope the inner legs up into the outer legs. Repeat on the opposite legs - making sure to do two legs at a time.




**2.** Stand under shelter and locate center hub. Place hand beneath center hub and hold while releasing top frame inner peak beams. Push snap buttons on all four top frame inner peak beams to disengage.



**Warning: After all four peak beam assembly snap buttons are released, gently lower center hub. Center hub should drop down in an inverted position and rest near the ground.**

**3.** Release top extension rods at each corner while depressing snap button with other hand.



**4.** Release auto slider at each corner. With one hand, push up on truss near slider to remove the weight of the shelter from snap button. Depress snap button and push slider down.



**5.** Grasp the top and bottom of the diamond on opposite sides by "close" sticker. Lift the shelter up slightly and shake it while stepping towards your partner until the unit is 3/4 closed. With each partner grasping two outer legs, push shelter together to fully close it. **Be careful not to pinch fingers!** Store E-Z UP® in carry bag.

