IMPORTANT INFORMATION

IMPORTANT! Read this information before proceeding. It is the user's responsibility to take the following precautions at all times.

- Always stake or weight down your E-Z UP®. Do not use in any potentially windy or rainy weather. Wind and rain can damage the E-Z UP® Instant Shelter® and may also result in injury to you or others. Therefore, do not rely on shelter for protection in heavy or prolonged rain storms.
- The E-Z UP® Instant Shelter® is designed as a temporary shelter. Do not leave up for extended periods.
- Use caution when handling the E-Z UP® folding frame. Avoid pinching hands or fingers as frame opens or closes.
- Do not use shelter in a lightning storm.
- Do not leave your E-Z UP® Instant Shelter® unattended.
- Keep all flame and heat sources away from fabric top. Do not build fires within shelter enclosure.

CARE AND MAINTENANCE

For long lasting durability and the best possible protection for your E-Z UP® Instant Shelter®, follow these E-Z care and maintenance instructions:

- Frame will operate and look better if occasionally wiped with silicone spray, especially before and after use in damp conditions.
 Remove excess silicone residue before applying top.
- Slightly tighten bolts if frame becomes loose.

For online warranty, service, parts and accessories as E-Z as 1-2-click, contact us at WWWOJAUDOGOM Ask about our other E-Z UP® Instant Products[™]



INTERNATIONAL E-Z UP, INC., manufacturer of the E-Z UP® Instant Shelter™, warrants to the original purchaser who provides a dated sales receipt, each part of the E-Z UP® Instant Shelter™ to be free from defects in material or workmanship for a period of **TWO YEARS** after the date of original purchase. This warranty applies only for normal and expected uses, as determined by the manufacturer. INTERNATIONAL E-Z UP, INC.'s obligation and liability under this warranty is limited to the repair or replacement (at its option) of the product or its parts, after its own review and examination.

RETURN ADVISORY - Before returning any part or product to INTERNATIONAL E-Z UP, INC. or its designated representative, please phone or write to obtain specific return shipping instructions. All shipping costs must be prepaid, and INTERNATIONAL E-Z UP, INC. is not responsible for products damaged in transit.

CONDITIONS - This warranty shall be void as to any product which has been altered or modified in any manner. This warranty does not apply to damages caused by wind, rain, or other forces of nature, not to accidental or deliberated damage of the product, nor to use of the product that does not conform with the product instructions.

This warranty is provided in lieu of all other warranties, expressed or implied.

We Make Life E-Z!™ INTERNATIONAL E-Z UP, INC.

1601 Iowa Avenue, Riverside, California 92507 (951) 781-0843 • Fax (951) 781-0586

www.ezup.com

(800) 45 SHADE

EZUP® INSTANT SHELTER®

"Sets Up in Seconds!™"

EURO**OOME**"11

10' x 10'

PART NUMBER: EDS20095NBL EDS20095RBL

Take time to learn how to provide years of durable and safe use from your E-Z UP® Instant Shelter®. After reading these instructions carefully, if you have any need of assistance, call our Customer Service Department.



(800) SHADE ME www.ezup.com

WHAT'S IN THE BOX

Please read each step before you attempt to set up. Save these instructions for future reference.

- 10' x 10' Frame
- 4 Piece Stake Kit





1 • Place your E-Z UP® frame in the center of area to be sheltered. With partner on opposite side, grasp two outer legs, slightly lift off ground and step backwards, stopping at full arms' lenath.



4. Lift adjacent outer leas and pull out inner legs until snap button locks.

3. Engage auto slider at each

corner by pushing up on slider with

one hand while pushing down on

top of leg with other hand. Snap

step on remaining legs.

button will engage in hole. Repeat



2. Grasp the top and bottom of diamond-shaped area of trusses near "open" stickers. Slightly lift shelter up and push hands together while stepping backwards until shelter is fully opened. Be careful not to pinch fingers or pull backwards too hard as trusses will bend.



5. Choose different height option by depressing snap button with your partner and lifting shelter until next snap button locks. Use stakes provided to secure.



• With a partner, lift adjacent outer legs slightly, depress snap button and telescope inner legs into outer legs. Repeat on remaining legs.



2. Release auto slider at each corner by first lifting hem of top. With one hand, push up on truss near slider to remove the weight of the shelter from snap button. Depress snap button and push slider down.



3. With partner on opposite side, grasp top and bottom of diamond-shaped area of trusses, near "close" stickers, and slightly lift up. Shake shelter slightly, pulling hands apart, while stepping towards partner until shelter is 3/4 closed.



4. Grasp adjacent outer legs and push shelter together until fully closed. Be careful not to pinch fingers!