


How to TAKE DOWN

1. With a partner, depress snap buttons and telescope inner legs into outer legs. Repeat on the opposite legs - making sure to do two legs at a time.




2. Remove top fabric and peak hardware.

3. Disengage the Auto Slider® at each corner. With one hand pull down on the truss near the slider and depress the snap button. Repeat on all corners.



4. With partner on opposite side, grasp two outer legs, slightly lift off the ground, and step forwards. Be careful not to pinch fingers.



ezup.com

CARE & MAINTENANCE

For long lasting durability and the best possible protection for your POP lite, follow these E-Z care and maintenance instructions:

- Use a mild soap (not detergent) and plenty of water for top cleaning.
- Let the top and frame dry completely before closing or storing to avoid mildew. Inner legs must be dry and clean before storing inside outer legs.
- Frame will operate better if occasionally wiped with silicone spray on inner and outer legs, especially before and after use in damp conditions. Remove excess silicone.

IMPORTANT INFORMATION

IMPORTANT! Read this information before proceeding. It is the user's responsibility to take the following precautions at all times.

- Use caution when handling the E-Z UP® folding frame. Avoid pinching hands or fingers as frame opens or closes.
- Always securely stake or weight down your shelter. Wind and rain can damage the POP lite and may also result in injury to you or others. Therefore, do not rely on shelter for protection in heavy or prolonged rain storms.

E-Z UP



WARRANTY

INTERNATIONAL E-Z UP, INC., manufacturer of the E-Z UP® POPlite™, warrants to the original purchaser who provides a dated sales receipt, each part of the E-Z UP® POPlite™ to be free from defects in material or workmanship for a period of two years after the date of original purchase. This warranty applies only for normal and expected uses, as determined by the manufacturer.

ezup.com

We Make Life E-Z!™
INTERNATIONAL E-Z UP, INC.

1900 Second Street, Norco, California 92860
(951) 279-0999 • Fax (951) 279-0888

ezup.com

Customer Service Hot Line
800-45 SHADE
8 0 0 - 4 5 7 - 4 2 3 3

POP^{lite}™



4' x 4'

Peak Top Assembly

With proper care, this shelter will deliver years of trouble free service. Please take a few minutes to read the following use and care instructions. If you have any questions or require assistance, please call.



Customer Service Hot Line
800-45 SHADE

8 0 0 - 4 5 7 - 4 2 3 3

ezup.com


OWNER'S MANUAL

WHAT'S INCLUDED


(1) POP lite™ 4'x4' Base Frame , (1) POP lite™ Peak Top
(4) Peak Wires, (1) Peak Hub

How to Set Up Frame


1. Place your frame in the center of area to be used. With partner on opposite side, grasp two outer legs, slightly lift off the ground, and step backwards, stopping at full arms length.



2. Grasp the bottom of the trusses on opposite sides. Lift up and step backwards until shelter is fully opened, being careful not to pinch fingers.



3. Engage the Auto Slider® at each corner. With one hand hold the cap on the top of the leg, push up on the slider with the other hand. The snap button will engage in the hole. Repeat on all corners.



4. Assemble top according to your POP lite top specifications. **See Top Assembly Instructions.**

5. Lift the two adjacent outer legs and slide out the inner legs until the snap button locks into the hole in the outer leg. Repeat on the opposite legs - make sure to lower two legs at a time.



Top Assembly Instructions

How to Set Up Top

1. After completing the frame set up step 3, insert the 60 degree angled long end of the peak wire into the cap on the top of the leg. Insert into the inside hole. Repeat on all corners.




2. Connect the four ends of the peak wires together by inserting the 30 degree angled short end of the peak wire into the round peak hub.



3. Gently unfold the fabric and place it over the open frame.

4. Attach the fabric top to the frame by matching the quick attachment strips on the fabric with the quick attachment strips on the frame. Pull the corners down fully. Push the strips firmly together at each corner. Repeat on all corners.



5. Continue frame set up.


Accessory Instructions

How to Set Up RAILSKIRT


1. Once the shelter is completely set up, slide the beam wire into the top sleeve of the railskirt fabric.



2. Insert one beam wire end into the hole on the outer leg of the shelter just above the snap button of the telescoping leg.



3. Place the other side of the beam wire end into the slot on the opposite leg and push down firmly until the beam wire is securely seated into place. Secure fabric with attachment straps around the leg.



[To remove, repeat steps in reverse order.]

How to Set Up SIDEWALL

Attach sidewall to frame as shown.

1. Wrap the long attachment straps around truss. The top of the sidewall tucks underneath the valance of the top fabric.

2. Wrap short attachment straps around the legs.



[To remove, repeat steps in reverse order.]