IMPORTANT INFORMATION

IMPORTANT! Read this information before proceeding. It is the user's responsibility to take the following precautions at all times.

- Always stake or weight down your QUEST™ Canopy. Do not use in any
 potentially windy or rainy weather. Wind and rain can damage your
 QUEST™ Canopy and may also result in injury to you or others. Therefore,
 do not rely on shelter for protection in heavy or prolonged rain storms.
- The QUEST™ Canopy is designed as a temporary sun shelter. Do not leave up for extended periods.
- Use caution when handling the QUEST™ Canopy frame. Avoid pinching hands or fingers as frame opens or closes.
- Do not use shelter in a lightning storm.
- Do not leave your QUEST™ Canopy product unattended.
- Do not build fires under shelter.

WARNING: Keep all flame and heat sources away from the top fabric. This fabric meet the flammability requirements of CPAI-84. The fabric may burn it left in continuous contact with any flame source. The application of any foreign substance to the fabric may render the flame-resistant properties ineffective.

CARE AND MAINTENANCE

For long lasting durability and the best possible protection for your Quest™ Canopy product, follow these care and maintenance instructions:

- Use a mild soap (not detergent) and plenty of water for top cleaning.
- Let the Quest[™] top and frame dry completely before closing or storing to avoid mildew.
- Frame will operate and look better if occasionally wiped with silicone spray, especially before and after use in damp conditions. Remove excess silicone residue before attaching top.
- Use a seam sealer if top leaks or drips water. Available at most sporting goods and hardware stores.
- Slightly tighten bolts if frame becomes loose.

•QUEST•

1 YEAR LIMITED WARRANTY

Z-Shade™, manufacturer of the Quest™ Canopy product, warrants to the original purchaser who provides a dated sales receipt from an Authorized Quest™ Dealer, each part of the Quest™ Canopy to be free from defects in material or workmanship for a period of one year after the date of original purchase. The Quest™ Canopy frame is covered under a limited one year warranty and guarantees the frame to be free from defects in material or workmanship. This warranty applies only for normal and expected uses, as determined by the manufacturer.

Z-Shade's obligation and liability under this warranty is limited to the repair or replacement (at its option) of the product or its parts, after its own review and examination.

CONDITIONS - This warranty shall be void as to any product which has been altered or modified in any manner. This warranty does not apply to damages caused by wind, rain, or other forces of nature, not to accidental or deliberate damage of the product, nor to use of the product that does not conform with the product instructions.

This warranty is provided in lieu of all other warranties, expressed or implied.

•QUEST•

CUSTOMER SERVICE HOT LINE

1 (800) SHADE ME

1601 Iowa Avenue, Riverside, California 92507 (909) 426-0060 ● Fax (909) 426-0063

•QUEST• CANOPY



6ft x 6ft (1.8m x 1.8m)

Take time to learn how to provide years of durable and safe use from your QUEST™ Canopy product. After reading these instructions carefully, if you have any need of assistance, call our Customer Service Department.

•QUEST•

Customer Service Hot Line
1 (800) SHADE ME

WHAT'S IN THE BOX

- QUEST™ Frame
- Polyester Top
- Carry-Bag
- 4 Piece Stake Kit

FIRST TIME TOP

Please read each step before you attempt to set up. Save these instructions for future reference.



■ Place your QUEST™ frame in the center of area to be shaded. With partner on opposite side, grasp two outer legs, slightly lift off ground and step backwards, stopping at full arms' length.




2. Gently unfold the fabric top and place it over the open frame.



3. Secure the top to the frame by pulling the valance of the top down and matching the hook and loop strips on the frame. Push the hook and loop strips firmly together at each corner.

HOW TO SET UP

First: Repeat Step 1, in 'First Time Top Attachment'



1. Grasp the bottom of the diamond shaped area of trusses on opposite sides by the "open" sticker. Lift up and step backwards until shelter is fully opened, being careful not to pinch fingers.




corner, first lift the fabric off of the slider, then with one hand hold the top of the leg while pushing up on the slider with the hand. The Pull Pin will engage the hole. Pull down the fabric valance over the slider. Repeat on all four comers.

2. To engage Pull Pin Slider at each



3. Lift the two adjacent outer legs up and slide out the inner leg until the snap button locks. Now, slide out the bottom inner leg until the snap button locks. Repeat on the opposite legs -make sure to do the two leas at a time on same side.


How To TAKE DOWN



T • With partner, slightly lift up the two adjacent outer legs 1", depress snap button and slide bottom inner leg into outer leg. Now, depress next snap button and slide inner leg into outer leg. Repeat on the opposite legs making sure to do two legs at a time on same side.



2. Release the Pull Pin slider at each corner by first lifting fabric top corner and pull the pin out to release.



3. Grasp the top diamond on opposite sides by "close" sticker. Lift the shelter up slightly and shake it while stepping towards your partner until the unit is 3/4 closed. With partner grasp two outer legs and push frame together to fully close it.

Be careful not to pinch fingers. Store shelter in Carry-Bag.