


Wedge™ Replacement Parts

Part Description	Part Number	Price Each
Replacement Frame	BWF1567	\$109.97
Replacement Top	BWT1626BY	58.48
Outer Leg #1	INPOL11768W	14.50
Outer Leg #2	INPOL21767W	14.50
Outer Leg #3	INPOL31766W	14.50
Outer Leg Cap #1	BWPLC1583	2.50
Outer Leg Cap #2	BWPLC1590	2.50
Outer Leg Cap #3	DMPLC4375	2.50
Slider #1	BWPSL1600	4.50
Slider #2	BWPSL1591	4.50
Slider #3	DMPLS0000	4.50
Truss 31 ½"	BWPTR1571W-TC	7.50
Truss 45 ¾"	DMPTR1491W-TC	7.50
Truss, Long 44 ¾"	BWPTR1708W-TC	7.50
Truss, Slider Long	INPTR1762W-TC	12.00
Truss, Slider Short 32 1/2"	INPTR1763W-TC	7.50
Fiberglass Rod	BWPTP1659	10.00
Hook, Top Attachment	INPTH0000	2.00
Cover Bag	BWACB1706	9.95



ASK ABOUT OUR OTHER E-Z UP™ INSTANT PRODUCTS™

Customer Service Hot Line

(800) 810-0143



PRODUCT

WARRANTY

INTERNATIONAL E-Z UP, INC., manufacturer of the E-Z UP® Instant Shelter®, warrants to the original retail purchaser who has properly completed and returned the enclosed warranty registration card, each part of the E-Z UP® Instant Shelter® to be free from defects in material or workmanship for a period of one year after the date of original purchase. This warranty applies only for normal and expected uses, as determined by the manufacturer. INTERNATIONAL E-Z UP, INC.'s obligation and liability under this warranty is limited to the repair or replacement (at its option) of the product or its parts, after its own review and examination.

RETURN ADVISORY - Before returning any part or product to INTERNATIONAL E-Z UP, INC. or its designated representative, please phone or write to obtain specific return shipping instructions. All shipping costs must be prepaid, and INTERNATIONAL E-Z UP, INC. is not responsible for products damaged in transit.

CONDITIONS - This warranty shall be void as to any product which has been altered or modified in any manner. This warranty does not apply to damages caused by wind, rain, or other forces of nature, not to accidental or deliberated damage of the product, nor to use of the product that does not conform with the product instructions.

This express warranty is provided in lieu of all other warranties, expressed or implied.

We Make Life E-Z!™

INTERNATIONAL E-Z UP, INC.

Corporate and Manufacturing Headquarters 1601 Iowa Avenue, Riverside, California 92507 (909) 781-0843 • Fax (909) 781-0586

www.ezup.com

Customer Service Hot Line

(800) 810-0143

E-Z UP®



"Sets Up in 60 Seconds!"



Take time to learn how to provide years of durable and safe use from your E-Z UP® Instant Shelter®. After reading these instructions carefully, if you have any need of assistance, call our Wedge™ Customer Service



Customer Service Hot Line (800) 810-0143

What's In The Box

Please read each step before you attempt to set up. Save these instructions for future reference. Return the Warranty Card within 10 days of purchase.

- 1 Wedge[™] Frame Fully Assembled
- 1 Carry Bag

• 1 Wedae™ Top

• 3 Piece Stake Kit

How To Set Up

*Note: First Time Attachment Is Required

Top and frame are shipped unattached to avoid damage. A first time set up requires that the top be attached to the frame. This first-time set up takes longer than 60 seconds. Once top is permanently attached to frame, set up and take down are easily accomplished within 60 seconds.



Place your E-Z UP® frame in the center of area to be shaded Stand in front of shelter, grasp outer legs and extend arms to partially open shelter - approximately 3/4 its total size.




*2. Gently unfold the fabric top and place it over the open frame. The front of the frame will have the large diamond truss.



*3. Attach J-hooks sewn on the top into holes located in the bottom of the legs.



4. Stand in front of shelter, grasp large center diamond on upper left and lower right side and press diamond together until front auto-sliders engage snap buttons on front leas.



5. Walk ground back of shelter and lift fabric. Engage auto-slider by pushing up on slider with one hand while pushing down on top of lea with other hand. The snap button will enaage in hole. Pull out fabric.




6. Reach under shelter and locate flex rod clipped to inside of trusses. Remove flex rod from clip. Firmly insert end of flex rod that is attached to frame in plastic corner bracket hole. Place the other end of the flex rod in the pouch on the front of the top.



7. Stake down your E-Z UP® with the stakes provided. Fill sewn in pockets with sand for added stability.

*Note: Once top is permanently attached only preform steps 4 - 7.

How To Take Down




Remove end of flex rod that is attached to frame in plastic corner bracket hole and clip rod into retaining clip located on the



2. Release auto-slider at all three corners by slightly lifting up on slider with one hand while depressing snap button with other hand. Once snap button is depressed, push slider down past snap button.







4. Grasp adjacent outer legs and push shelter together until fully closed. Be careful not to pinch fingers! Store E-Z UP® in cover bag.

Important Information

IMPORTANT! Read this information before proceeding. It is the user's responsibility to take the following precautions at all times.

- Use caution when handling the E-Z UP® folding frame. Avoid pinching hands or fingers as frame opens or closes.
- Always stake or weight down your E-Z UP®. Do not use in any potentially windy or rainy weather. Wind and rain can damage the E-Z UP® Wedge™ and may also result in injury to you or others. Therefore, do not rely on shelter for protection in heavy or prolonged rain storms.
- Do not use shelter in a lightning storm.
- The E-Z UP® Wedge[™] is designed as a temporary shelter. Do not leave up for extended periods.
- Do not leave your E-Z UP® Wedge™ unattended.
- Keep all flame and heat sources away from top fabric. Do not build fires within shelter enclosure

Care and Maintenance

For long lasting durability and the best possible protection for your E-Z UP® Wedge™, follow these E-Z care and maintenance instructions:

- Use a mild soap (not detergent) and plenty of water for cleaning top
- Let the E-Z UP® top and frame dry completely before closing or storing,
- Frame will operate and look better if occasionally wiped with silicone spray, especially before and after use in damp conditions. Remove excess silicone residue before applying top.
- Slightly tighten bolts if frame becomes loose.

Customer Service Hot Line (800) 810-0143