



Instructions For POP UP DISPLAY WALL

Box includes:

(1) Carry Bag, (1) Pop Up Display Frame, (1) Fabric Display Wall

SET UP

1. Place your E-Z UP® product in the center of the area intended to display.

2. Open **Display Wall Frame** completely.

Align all **Locking Arms** and snap all into place. (Fig A)

WARNING!

To avoid damage to Locking Arm, ensure webbing is not wrapped around Locking Arm prior to opening. (Fig B)

3. Attach the **Fabric Display Wall** to the **Display Wall Frame** by locating the **Hook** strips on the **Fabric Display Wall** and the **Loop** strips on the **Display Wall frame** corners. Beginning on one corner, push the **Hook** and **Loop** strips firmly together and continue to the next corner until all are secured. (Fig C)

Secure remaining sides. (Fig D)

4. Stand Display Wall upright. (Fig E)

TAKE DOWN

Repeat steps in reverse of assembly.

WARNING!

To avoid damage to the Locking Arms, ensure that the arms are unlocked and aligned. (Fig F)


CARE & MAINTENANCE

- Use a mild soap (not detergent) and plenty of water for cleaning.


Let the E-Z UP® Pop Up Display Wall dry completely before closing or storing to avoid mildew.

- Store in the Carry Bag Provided.


(Fig A) Display Wall Frame



(Fig B)




(Fig C)



(Fig D)



(Fig E)



(Fig F)

